

C19 IP camera SD card slot location

1, Disassemble camera front lens as shown in following picture.



2, Unscrew front 2 screws as shown in following picture.



3, You can see camera SD card slot on main board, insert your SD card, assemble camera front lens.

