


How to Locate Camera SD Card Slot


1. Open the four screws.




2. You will see the following picture when you disassemble the cover.




3. The red frame is showing the SD slot.



4. Insert the SD card



5. Press SD card in slot gently.



6. Put the four screws back after installing sucessfully

